## **Robot keyboard control**

Note: The virtual machine needs to be in the same LAN as the car, and the ROS\_DOMAIN\_ID needs to be consistent. You can check [Read me] to set the IP and ROS\_DOMAIN\_ID on the board.

## 1. Program function description

After the program is started, the car movement can be controlled through the keyboard.

## 2. Start and connect to the agent

Taking the supporting virtual machine as an example, enter the following command to start the agent:

```
sudo docker run -it --rm -v /dev:/dev -v /dev/shm:/dev/shm --privileged --
net=host microros/micro-ros-agent:humble udp4 --port 8090 -v4
```

Then, turn on the car switch and wait for the car to connect to the agent. The connection is successful, as shown in the figure below.

```
| create_participant
                                                                           participant created
                                                                                                   | client_key: 0x0B62A009, part
icipant_id: 0x000(1)
                                                | create_topic
                                                                                                   | client_key: 0x0B62A009, topi
c_id: 0x000(2), participant_id: 0x000(1)
                                                | create_publisher
                                                                           | publisher created
                                                                                                  | client_key: 0x0B62A009, publ
isher_id: 0x000(3), participant_id: 0x000(1)
                                                | create_datawriter
                                                                                                   | client_key: 0x0B62A009, data
create_topic
                                                                                                   | client key: 0x0B62A009, topi
c_id: 0x001(2), participant_id: 0x000(1)
                                                | create publisher
                                                                                                  | client key: 0x0B62A009, publ
isher_id: 0x001(3), participant_id: 0x000(1)
                                                                                                  | client_key: 0x0B62A009, data
writer_id: 0x001(5), publisher_id: 0x001(3)
                                                | create_topic
                                                                                                  | client_key: 0x0B62A009, topi
c_id: 0x002(2), participant_id: 0x000(1)
                                                                                                  | client_key: 0x0B62A009, publ
                                                | create_publisher
isher_id: 0x002(3), participant_id: 0x000(1)
                                                                                                  | client key: 0x0B62A009, data
                                                I create datawriter
writer_id: 0x002(5), publisher_id: 0x002(3)
                                                | create_topic
                                                                                                  | client_key: 0x0B62A009, topi
c_id: 0x003(2), participant_id: 0x000(1)
                                                                                                  | client_key: 0x0B62A009, subs
criber_id: 0x000(4), participant_id: 0x000(1)
                                                                                                  | client_key: 0x0B62A009, data
                                                | create datareader
reader_id: 0x000(6), subscriber_id: 0x000(4)
                                                I create topic
                                                                                                  | client key: 0x0B62A009, topi
c_id: 0x004(2), participant_id: 0x000(1)
                                                                                                  | client_key: 0x0B62A009, subs
criber_id: 0x001(4), participant_id: 0x000(1)
                                                | create_datareader
                                                                                                   | client_key: 0x0B62A009, data
reader_id: 0x001(6), subscriber_id: 0x001(4)
                                                                                                  | client_key: 0x0B62A009, topi
                                                | create_topic
c_id: 0x005(2), participant_id: 0x000(1)
                                                                                                  | client_key: 0x0B62A009, subs
                                                I create subscriber
criber_id: 0x002(4), participant_id: 0x000(1)
                                                | create_datareader
                                                                                                  | client_key: 0x0B62A009, data
 eader_id: 0x002(6), subscriber_id: 0x002(4)
```

## 3. Start the keyboard control program

Enter the following command in the terminal to start the keyboard control program.

ros2 run yahboomcar\_ctrl yahboom\_keyboard

```
yahboom@yahboom-VM:~$ ros2 run yahboomcar_ctrl yahboom_keyboard

Control Your SLAM-Bot!

Moving around:

u i o
j k l
m , .

q/z: increase/decrease max speeds by 10%

w/x: increase/decrease only linear speed by 10%

e/c: increase/decrease only angular speed by 10%

t/T: x and y speed switch

s/S: stop keyboard control

space key, k: force stop

anything else: stop smoothly

CTRL-C to quit

currently: speed 0.2 turn 1.0
```

Keyboard key descriptions are as follows

Directional control.

[i] or [I]	[linear, 0]	[u] or [U]	[linear, angular]
[,]	[-linear, 0]	[o] or [U]	【linear, -angular】
[j] or [J]	[0, angular]	[m] or [M]	[-linear, -angular]
[I] or [L]	[0, -angular]	[.]	[-linear, angular]

According to the control table description, you can go forward by pressing the [i] key. Press [,] to go back, Press [l] to rotate to the right, press [j] to rotate to the left, and so on.

speed control table

speed change	speed change	keyboard keys	speed change
<b>[</b> q]	Linear speed and angular speed increased by 10%	[z]	Linear speed and angular speed are reduced by 10%
[w]	Only line speed increases by 10%	[x]	Only line speed is reduced by 10%
[e]	Only the angular velocity is increases by 10%	[c]	Only the angular velocity is reduced by 10%
[t]	Linear speed X-axis/Y-axis direction switching	[s]	Stop keyboard control

Note: Since the car has a four-wheel drive structure with ordinary tires and cannot move sideways, the [t] button has no meaning. Before each use of keyboard control, you need to click on the terminal that starts the program, otherwise the key event cannot be detected.